

Ride Over Gate

Installation Instructions

NB. If installing for irrigator, ensure wheels run as much over the centre of the gate as possible.

1. From vertical: Pull chains up to hooks and check pendulum action.
Ensure rocker mechanism does not come into contact with dirt.
2. Build up dirt ramps either side so Gate Frame is supported once on the ground.
3. Grease rocker mechanism at least once a month (depending on use).
Separate Base Frame and gate frame by unhooking chains from latches on side of gate.
Remove Gate Frame on about a 20° angle from vertical.
4. Put first post in the ground in desired position at normal height.
5. Bring ROG Base Frame flush with post and raise approx. 50mm off the ground. The easiest way to do this is to use some bits of 100 x 50 or 150 x 50 timber.
6. Line up second post flush with other side of Base Frame and ram or dig hole and sink post in.
7. Mark holes for drilling with 12-13mm auger (depending on how dry the posts are).
8. Drill holes. Lower Base Frame back, then put coach bolts in place.
9. Once bolts are tight, slide main gate frame into base frame at approx 20°.

YouTube video of these Installation Instructions can be found at
www.thewrangler.co.nz/rog

